


**AWS C4.9/C4.9M:2024**  
**An American National Standard**



# **Recommended Practices for Oxyacetylene Cutting of Steel**



**AWS C4.9/C4.9M:2024**  
**An American National Standard**

**Approved by the**  
**American National Standards Institute**  
**October 17, 2024**

# **Recommended Practices for Oxyacetylene Cutting of Steel**

**1st Edition**

Prepared by the  
American Welding Society (AWS) C4 Committee on Oxyfuel Gas Welding and Cutting

Under the Direction of the  
AWS Technical Activities Committee

Approved by the  
AWS Board of Directors

## **Abstract**

This recommended practice for oxyacetylene cutting includes general procedures to be used in conjunction with oxyacetylene equipment and the latest safety recommendations. If not found in this recommended practice, lists of additional equipment are available from individual manufacturers.



ISBN Print: 978-1-64322-332-2  
ISBN PDF: 978-1-64322-333-9  
© 2024 by American Welding Society  
All rights reserved  
Printed in the United States of America

**Photocopy Rights.** No portion of this standard may be reproduced, stored in a retrieval system, or transmitted in any form, including mechanical, photocopying, recording, or otherwise, without the prior written permission of the copyright owner.

Authorization to photocopy items for internal, personal, or educational classroom use only or the internal, personal, or educational classroom use only of specific clients is granted by the American Welding Society provided that the appropriate fee is paid to the Copyright Clearance Center, 222 Rosewood Drive, Danvers, MA 01923, tel: (978) 750-8400; Internet: <[www.copyright.com](http://www.copyright.com)>.

## Statement on the Use of American Welding Society Standards

All standards (codes, specifications, recommended practices, methods, classifications, and guides) of the American Welding Society (AWS) are voluntary consensus standards that have been developed in accordance with the rules of the American National Standards Institute (ANSI). When AWS American National Standards are either incorporated in, or made part of, documents that are included in federal or state laws and regulations, or the regulations of other governmental bodies, their provisions carry the full legal authority of the statute. In such cases, any changes in those AWS standards must be approved by the governmental body having statutory jurisdiction before they can become a part of those laws and regulations. In all cases, these standards carry the full legal authority of the contract or other document that invokes the AWS standards. Where this contractual relationship exists, changes in or deviations from requirements of an AWS standard must be by agreement between the contracting parties.

AWS American National Standards are developed through a consensus standards development process that brings together volunteers representing varied viewpoints and interests to achieve consensus. While AWS administers the process and establishes rules to promote fairness in the development of consensus, it does not independently test, evaluate, or verify the accuracy of any information or the soundness of any judgments contained in its standards.

AWS disclaims liability for any injury to persons or to property, or other damages of any nature whatsoever, whether special, indirect, consequential, or compensatory, directly or indirectly resulting from the publication, use of, or reliance on this standard. AWS also makes no guarantee or warranty as to the accuracy or completeness of any information published herein.

In issuing and making this standard available, AWS is neither undertaking to render professional or other services for or on behalf of any person or entity, nor is AWS undertaking to perform any duty owed by any person or entity to someone else. Anyone using these documents should rely on his or her own independent judgment or, as appropriate, seek the advice of a competent professional in determining the exercise of reasonable care in any given circumstances. It is assumed that the use of this standard and its provisions is entrusted to appropriately qualified and competent personnel.

This standard may be superseded by new editions. This standard may also be corrected through publication of amendments or errata, or supplemented by publication of addenda. Information on the latest editions of AWS standards including amendments, errata, and addenda is posted on the AWS web page ([www.aws.org](http://www.aws.org)). Users should ensure that they have the latest edition, amendments, errata, and addenda.

Publication of this standard does not authorize infringement of any patent or trade name. Users of this standard accept any and all liabilities for infringement of any patent or trade name items. AWS disclaims liability for the infringement of any patent or product trade name resulting from the use of this standard.

AWS does not monitor, police, or enforce compliance with this standard, nor does it have the power to do so.

Official interpretations of any of the technical requirements of this standard may only be obtained by sending a request, in writing, to the appropriate technical committee. Such requests should be addressed to the American Welding Society, Attention: Managing Director, Standards Development, 8669 NW 36 St, # 130, Miami, FL 33166 (see Annex E). With regard to technical inquiries made concerning AWS standards, oral opinions on AWS standards may be rendered. These opinions are offered solely as a convenience to users of this standard, and they do not constitute professional advice. Such opinions represent only the personal opinions of the particular individuals giving them. These individuals do not speak on behalf of AWS, nor do these oral opinions constitute official or unofficial opinions or interpretations of AWS. In addition, oral opinions are informal and should not be used as a substitute for an official interpretation.

This standard is subject to revision at any time by the C4 Committee on Oxyfuel Gas Welding and Cutting. It must be reviewed every five years, and if not revised, it must be either reaffirmed or withdrawn. Comments (recommendations, additions, or deletions) and any pertinent data that may be of use in improving this standard are requested and should be addressed to AWS Headquarters. Such comments will receive careful consideration by the C4 Committee on Oxyfuel Gas Welding and Cutting and the author of the comments will be informed of the Committee's response to the comments. Guests are invited to attend all meetings of the C4 Committee on Oxyfuel Gas Welding and Cutting to express their comments verbally. Procedures for appeal of an adverse decision concerning all such comments are provided in the Rules of Operation of the Technical Activities Committee. A copy of these Rules can be obtained from the American Welding Society, 8669 NW 36 St, # 130, Miami, FL 33166.

This page is intentionally blank.

# Personnel

## **AWS C4 Committee on Oxyfuel Gas Welding and Cutting**

L. L. Liston, Chair	<i>Consultant</i>
B. F. Johnson, 1st Vice Chair	<i>Miller Electric Mfg. LLC</i>
C. J. Leak, 2nd Vice Chair	<i>The Harris Products Group</i>
M. K. Gills, Secretary	<i>American Welding Society</i>
J. M. Rosario, Secretary	<i>American Welding Society</i>
E. A. Abbott	<i>Ironworkers International Union (retired)</i>
J. D. Compton	<i>JD &amp; Associates (retired)</i>
M. J. Hogan	<i>The Harris Products Group (retired)</i>
V. D. Kudanekar	<i>The Harris Products Group</i>
D. B. Overvaag	<i>Miller Electric Mfg. LLC (retired)</i>
M. E. Owens	<i>Columbus State Community College</i>
J. C. Papritan	<i>The Ohio State University (retired)</i>
C. C. Wheeler	<i>John Deere &amp; Company</i>

## **Advisors to the AWS C4 Committee on Oxyfuel Gas Welding and Cutting**

T. K. Ham	<i>ESAB Welding and Cutting Products</i>
J. F. Henderson	<i>ESAB Welding and Cutting</i>
N. J. Matson	<i>The Harris Products Group</i>
R. I. Najafabadi	<i>Iranian Institute of Welding and Nondestructive Testing (IWNT)</i>

## **Special Contributor to the AWS C4 Committee on Oxyfuel Gas Welding and Cutting**

K. S. Papritan	<i>Consultant</i>
----------------	-------------------

This page is intentionally blank.

# Foreword

This foreword is not part of this standard but is included for information purposes only.

Oxyacetylene cutting is active and thriving in educational laboratories and manufacturing facilities worldwide. This process is very useful in fabrication, maintenance, and repair work. The process is flexible and mobile, and it can be used as a stand alone process or as a supplement to other cutting processes in large fabricating facilities concerned with job-shop type work and industrial processes. AWS C4.9/C4.9M, *Recommended Practices for Oxyacetylene Cutting of Steel*, has been structured in a format like AWS C4.7/C4.7M, *Recommended Practices for Oxyacetylene Welding of Steel*, which provides flexibility in how users can apply these guidelines and recommendations. Users can choose to implement the entire AWS C4.9/C4.9M as a comprehensive recommended practice or selectively use specific sections (clauses and annexes) based on their needs and settings. This means that certain parts of the AWS C4.9/C4.9M, such as narratives and figures found in Clause 7, Clause 8, and Annex D, can be used independently (separately) or sequentially (in a specific order), depending on the requirements of the situation. This adaptability allows for better customization to different environments like offices, classrooms, laboratories, or field settings. The goal of the C4 Committee has been and continues to be improving the understanding and retention of information among diverse audiences. These audiences include end users (likely individuals who perform oxyacetylene cutting e.g., cutters, otherwise students), management (managers, otherwise supervisors) administration (instructors, otherwise teachers). Imparting the essential knowledge and skills of oxyacetylene cutting uses both pedagogical (teaching methods for young [ $<18$  years old] adult learners) and andragogical (teaching methods for older [ $>18$  years old] adult learners) approaches. In summary, AWS C4.9/C4.9M provides guidelines and recommendations for oxyacetylene cutting of steel, and it offers flexibility in how this recommended practice can be applied in various educational and practical settings to cater to a wide range of users. This is the first edition of the document.

The safety concerns necessary for AWS C4.9/C4.9M, *Recommended Practices for Oxyacetylene Cutting of Steel* are similar to those documented in AWS C4.2/C4.2M, *Recommended Practices for Oxyfuel Gas Cutting Torch Operation*, AWS C4.3/C4.3M, *Recommended Practices for Oxyfuel Gas Heating Torch Operation*, AWS C4.4/C4.4M, *Recommended Practices for Heat Shaping and Straightening with Oxyfuel Gas Heating Torches*, AWS C4.7/C4.7M, *Recommended Practices for Oxyacetylene Welding of Steel* and ANSI Z49.1, *Safety in Welding, Cutting, and Allied Processes*.

This recommended practice describes the equipment, applications, and safe practices for oxyacetylene cutting operations. It can be used as a teaching and training tool to safely operate an oxyacetylene torch in cutting operations. This document is intended for use by the oxyacetylene cutter or his or her instructor. This recommended practice includes all the information necessary for the end users (cutters, otherwise students) and management (managers, otherwise supervisors) or administration (instructors, otherwise teachers) to oxyacetylene cut steel. Oxyacetylene cutting produces high-quality cuts. It is inexpensive, flexible, and mobile. It requires no electricity. It is clean and produces little slag or spatter. Much of the information in this recommended practice is general in nature. There is a variety of equipment available from several manufacturers; therefore, it is recommended that each manufacturer's equipment manual be consulted for details concerning the selection, setup, maintenance, and troubleshooting of said equipment before using it.

Acetylene is the primary fuel gas to be considered in this document. The other alternative fuel gases (i.e., propane, propylene, and natural gas) are viable fuel gases for gas cutting, but the equipment is different than that which is used for oxyacetylene cutting (OFC-A). This process (i.e., oxyfuel gas cutting) will be hereby known as oxyacetylene cutting in this recommended practice. Thus, oxyacetylene cutting can be used to cut steel pipe and tubing, sheet metal, and small-sized structural steel shapes and bars. It does not cover cutting in confined spaces, cutting over coatings of any kind, and cutting where there may be exposure to potentially hazardous substances.



The Ohio State University, on behalf of its Cooperative Extension Service has granted the American Welding Society (AWS) permission to use copyrighted images in AWS C4.9/C4.9M, *Recommended Practices for Oxyacetylene Cutting of Steel*. These images are not currently included in any print publication or product by the Ohio State University Extension. In each instance where an Ohio State University Extension image is used, the following source line has been included, "Courtesy of Ohio State University Extension."

Comments and suggestions for the improvement of this recommended practice are welcome. They should be sent to the Secretary, AWS C4 Committee on Oxyfuel Gas Welding and Cutting, American Welding Society, 8669 NW 36 St, # 130, Miami, FL 33166-6672.

# Table of Contents

	<b>Page No.</b>
<i>Personnel</i> .....	v
<i>Foreword</i> .....	vii
<i>List of Tables</i> .....	xi
<i>List of Figures</i> .....	xi
<b>1. General Requirements</b> .....	<b>1</b>
1.1 Scope .....	1
1.2 Units of Measure .....	1
1.3 Safety .....	1
<b>2. Normative References</b> .....	<b>3</b>
<b>3. Terms and Definitions</b> .....	<b>5</b>
<b>4. Oxyacetylene Cutting Process</b> .....	<b>7</b>
4.1 The Gases Used in Oxyacetylene Cutting .....	7
<b>5. Safety with Oxyacetylene Cutting</b> .....	<b>9</b>
5.1 Personal Protective Equipment (PPE) .....	9
5.2 Eye Protection .....	9
5.3 Footwear, Clothing, and Gloves .....	13
5.4 Ventilation .....	15
5.5 Avoiding Fires and Burns .....	16
5.6 Safe Use, Handling, and Storage of Gas Cylinders .....	17
5.7 Leak Detection Products .....	19
5.8 Safe Working Environment .....	20
<b>6. Equipment and Supplies for Oxyacetylene Cutting</b> .....	<b>21</b>
6.1 Cylinders .....	21
6.2 Regulators .....	27
6.3 Reverse Flow Check Valves and Flashback Arrestors .....	29
6.4 Hoses .....	31
6.5 Torches .....	32
6.6 Tips .....	33
6.7 Additional Oxyacetylene Equipment .....	35
<b>7. Startup and Shutdown Procedures for Oxyacetylene Cutting</b> .....	<b>39</b>
7.1 Cylinders .....	39
7.2 Equipment Connection .....	41
7.3 Setting the Correct Pressures .....	47
7.4 Testing for Leaks .....	54
7.5 Lighting the Torch .....	54
7.6 General Torch Settings .....	58
7.7 Shutting Off the Torch .....	60
7.8 Shutting Off the Source and Purging the Oxygen and Acetylene from the System .....	61
<b>8. Basic Cutting Techniques for Oxyacetylene Cutting</b> .....	<b>67</b>
8.1 Setting Up the Oxyacetylene Cutting System .....	67
8.2 Changing Welding Attachments to Cutting Attachments .....	68
8.3 Cutting Torches .....	69
8.4 Oxyacetylene Cutting Tips .....	70
8.5 Setting the Correct Working Pressure for Cutting .....	71
8.6 Lighting the Oxyacetylene Cutting Torch .....	77

	<b>Page No.</b>
8.7 Remember Safety First . . . . .	83
8.8 Cleanliness of Metal Being Cut . . . . .	83
8.9 Cutting Techniques . . . . .	83
8.10 Methodology for Making a Straight Oxyacetylene Cut . . . . .	83
8.11 Backfires and Flashbacks . . . . .	88
8.12 Shutting Down the Oxyacetylene System . . . . .	88
Annex A (Informative)—Informative References . . . . .	95
Annex B (Informative)—Terms and Definitions . . . . .	97
Annex C (Informative)—Fuel Gas (Acetylene) Withdrawal Rates . . . . .	103
Annex D (Informative)—Advanced Cutting Techniques for Oxyacetylene Cutting . . . . .	105
Annex E (Informative)—Requesting an Official Interpretation on an AWS Standard . . . . .	145
List of AWS Documents on Oxyfuel Gas Welding and Cutting . . . . .	147

## List of Tables

Table		Page No.
1	Oxygen Cylinder Shapes and Information . . . . .	23
2	Acetylene Cylinder Shapes and Information . . . . .	25
3	Cutting Tip Selection Chart . . . . .	49 and 71
C.1	Fuel Gas (Acetylene) Withdrawal Rates . . . . .	103
D.1	Cutting Tip Selection Chart . . . . .	109
D.2	Troubleshooting the OFC Process . . . . .	133

## List of Figures

Figure		Page No.
1	Industrial Quality Safety Glasses . . . . .	10
2	Industrial Quality Safety Glasses . . . . .	10
3	Industrial Quality Safety Glasses . . . . .	10
4	Industrial Quality Safety Glasses—Temporary . . . . .	10
5	Industrial Quality Safety Goggles—Temporary . . . . .	11
6	Tinted Protective Face Shield . . . . .	11
7	Clear Protective Face Shield . . . . .	12
8	Protective Face Mask . . . . .	12
9	Oxyacetylene Cutting Mask – Not Suggested for Use . . . . .	13
10	Oxyacetylene Cutting Goggles – Not Suggested for Use . . . . .	13
11	Gauntlet Leather Welding Gloves . . . . .	13
12	Leather Protective Cape . . . . .	14
14	Cutter’s Cap . . . . .	14
13	Cotton Protective Jacket . . . . .	14
15	Earplugs . . . . .	15
16	Earmuffs . . . . .	15
17	Inadequate Ventilation . . . . .	16
18	Good Ventilation—Natural or Mechanical . . . . .	16
19	Oxygen from Cutting Torch Blowing Dirt from Arm . . . . .	17
20	Waste Materials Favorable to Unwanted and Dangerous Fires . . . . .	17
21	Securing Cylinders to a Wall . . . . .	18
22	Moving Cylinders by Cart . . . . .	18
23	Oxygen Cylinder . . . . .	21
24	Oxygen Cylinder Valve . . . . .	22
25	Acetylene Cylinder . . . . .	24
26	Oxyacetylene Cutting Setup on a 2-Wheeled Cart . . . . .	26
27	Acetylene Cylinder Valve . . . . .	26
28	Oxygen Regulator . . . . .	27
29	Acetylene Regulator . . . . .	27
30	Single Stage Regulator . . . . .	28
31	Two Stage Regulator . . . . .	28
32	Reverse Flow Check Valves for Regulators . . . . .	29
33	Reverse Flow Check Valves for the Torch Handle . . . . .	29
34	Flashback Arrestors . . . . .	30
35	Hoses . . . . .	31
36	Hoses Connecting Nuts . . . . .	31

<b>Figure</b>	<b>Page No.</b>
37	Sample Hose Damage . . . . . 32
38	Cutting Torch Cut Away . . . . . 32
39	Injector Torch . . . . . 33
40	Equal Pressure Torch . . . . . 33
41	Cutting Tip . . . . . 34
42	Cutting Tip Cleaning . . . . . 34
43	Tank Wrench . . . . . 35
44	T-Wrench . . . . . 35
45	Friction Lighter . . . . . 35
46	Cutting Tip Cleaners . . . . . 36
47	Chipping Hammer with Wire Brush . . . . . 36
48	Wire Brush . . . . . 37
49	C-Clamp . . . . . 37
50	Slip Joint Pliers . . . . . 37
51	Locking Pliers . . . . . 37
52	Open End Wrench . . . . . 38
53	Adjustable Wrench . . . . . 38
54	Cutting/Welding Table . . . . . 38
55	Oxyacetylene Cutting Setup on a 2-Wheeled Cart . . . . . 39
56	Cylinders on Cart with Cylinder Safety Caps in Place . . . . . 39
57	Cylinders Secured to a Wall with Cylinder Safety Caps Removed . . . . . 40
58	Cracking the Cylinder Valve . . . . . 41
59	Oxygen Regulator . . . . . 41
60	Acetylene Regulator . . . . . 41
61	Attach the Regulator to the Acetylene Cylinder Valve . . . . . 42
62	Turn the Oxygen Regulator Adjusting Screw Counterclockwise . . . . . 42
63	Attach the Flashback Arrestor to the Acetylene Regulator . . . . . 43
64	Attach the Hose to the Oxygen Flashback Arrestor . . . . . 44
65	Attach the Oxygen Reverse Flow Check Valves to Torch Handle . . . . . 44
66	Attach the Hose to Torch Handle . . . . . 45
67	Welding Tip Attached to Torch Handle . . . . . 45
68	Welding Tip Detached from Torch Handle . . . . . 46
69	Cutting Attachment to be Connected to Torch Handle . . . . . 46
70	Cutting Attachment Connected to Torch Handle . . . . . 46
71	Cutting Tip . . . . . 47
72	Open the Acetylene Cylinder Valve to Provide Pressure on Cylinder Side but not Outlet Side . . . . . 48
73	Adjust the Acetylene Regulator to the Desired Static Pressure on the Outlet Side . . . . . 50
74	Open the Acetylene Torch Valve on the Torch Handle . . . . . 50
75	Readjust Acetylene Regulator Adjusting Screw for Correct Dynamic Pressure . . . . . 51
76	Close the Acetylene Torch Valve on the Torch Handle . . . . . 51
77	Adjust Oxygen Regulator to the Desired Static Pressure on the Outlet Side . . . . . 52
78	Open the Oxygen Torch Valve on the Torch Handle . . . . . 52
79	Open the Oxygen Torch Valve on the Cutting Attachment . . . . . 53
80	Readjust the Oxygen Regulator Adjusting Screw for the Correct Dynamic Pressure . . . . . 53
81	Close the Oxygen Valve on the Cutting Attachment . . . . . 54
82	Open the Acetylene Torch Valve on the Torch Handle . . . . . 54
83	Light the Torch with a Friction Lighter . . . . . 55
84	Acetylene Flame after Lighting with a Friction Lighter . . . . . 55

<b>Figure</b>	<b>Page No.</b>
85	Adjusting the Size of the Acetylene Flame with the Acetylene Torch Valve on the Torch Handle . . . . .56
86	Acetylene Flame Burning in Air with Only Acetylene from the Acetylene Torch Valve on the Torch Handle . . . 56
87	Adjusting the Carburizing or Reducing Flame with Too Little Oxygen Using the Oxygen Torch Valve on the Cutting Torch Attachment . . . . .57
88	Adjusting the Neutral Flame with More Oxygen Using the Oxygen Torch Valve on the Cutting Torch Attachment . . . . .57
89	Adjusting the Oxidizing Flame with Excessive Oxygen Using the Oxygen Torch Valve on the Cutting Torch Attachment . . . . .58
90	Basic Flames of Oxyacetylene Cutting . . . . .59
91	Shut Off the Oxygen Torch Valve on the Cutting Attachment – First . . . . .60
92	Shut Off the Acetylene Torch Valve – Second . . . . .60
93	Close the Oxygen Cylinder Valve . . . . .61
94	Open the Oxygen Torch Valve on the Cutting Torch Attachment Draining the Oxygen System . . . . .61
95	Turn the Adjusting Screw Counterclockwise on the Oxygen Regulator . . . . .62
96	Close the Oxygen Torch Valve on the Cutting Torch Attachment . . . . .62
97	Close the Oxygen Torch Valve on the Torch Handle . . . . .63
98	Close the Acetylene Cylinder Valve . . . . .63
99	Open the Acetylene Torch Valve on the Torch Handle Draining the Acetylene System . . . . .64
100	Turn the Adjusting Screw Counterclockwise on the Acetylene Regulator . . . . .64
101	Close the Acetylene Torch Valve on the Torch Handle . . . . .65
102	Oxyacetylene Cutting System on a 2-Wheeled Cart . . . . .67
103	Welding Tip and Torch Mixer Attached to Torch Handle . . . . .68
104	Welding Tip and Torch Mixer Detached from Torch Handle . . . . .68
105	Connecting a Cutting Attachment to the Torch Handle . . . . .68
106	Cutting Attachment Connected to Torch Handle . . . . .69
107	Combination (Hand) Cutting Torch . . . . .69
108	Commercial (Straight) Cutting Torch . . . . .70
109	Cutting Tip . . . . .70
110	There should be No Pressure on Adjusting Screws (Open or Loose) of either the Oxygen or Acetylene Regulators . . . . .72
111	Opening the Acetylene Cylinder Valve with Pressure on Cylinder Side but Not Output Side . . . . .72
112	Opening the Oxygen Cylinder Valve with Pressure on Cylinder Side but Not Output Side . . . . .73
113	Adjust Acetylene Regulator for Desired Static Pressure on the Output Side with Pressure on the Cylinder Side . . . . .73
114	Open the Acetylene Torch Valve on the Torch Handle . . . . .74
115	Readjust the Acetylene Regulator Adjusting Screw for the Correct Dynamic Pressure . . . . .74
116	Close the Acetylene Torch Valve on the Torch Handle . . . . .75
117	Adjust Oxygen Regulator for the Desired Static Pressure on the Output Side and Pressure on the Cylinder Side . . . . .75
118	Fully Open the Oxygen Valve on the Torch Handle – First . . . . .76
119	Open the Oxygen Needle Valve on the Cutting Attachment – Second . . . . .76
120	Readjust the Oxygen Regulator Adjusting Screw for the Correct Dynamic Pressure . . . . .77
121	Close the Oxygen Torch Valve on the Cutting Attachment – Only . . . . .77
122	Open the Acetylene Torch Valve on the Torch Handle . . . . .78
123	Light the Torch with a Friction Lighter . . . . .78
124	Acetylene Flame after Lighting with a Friction Lighter . . . . .79
125	Adjusting the Size of the Acetylene Flame with the Acetylene Torch Valve on the Torch Handle . . . . .79
126	Acetylene Flame Burning in Air with Only Acetylene from the Acetylene Torch Valve on the Torch Handle . . . 80
127	Adjusting the Carburizing or Reducing Flame with Some (Too Little) Oxygen Using the Oxygen Torch Valve on the Cutting Attachment . . . . .80

<b>Figure</b>	<b>Page No.</b>
128	Adjusting the Neutral Flame with More Oxygen Using the Oxygen Torch Valve on the Cutting Attachment . . . . . 81
129	Adjusting Neutral Flame with Cutting Oxygen Stream Using the Oxygen Cutting Lever on the Cutting Attachment . . . . . 81
130	Adjusting Oxidizing Flame with Excessive Oxygen Using the Oxygen Valve on the Cutting Attachment . . . . . 82
131	Basic Flames of Oxyacetylene Cutting . . . . . 82
132	A Straight Cut. . . . . 83
133	Torch Angle(s) for a Straight Cut. . . . . 84
134	Torch Height for a Straight Cut . . . . . 84
135	Torch Speed for a Straight Cut. . . . . 85
136	Start a Straight Cut. . . . . 85
137	Run a Straight Cut . . . . . 86
138	Stop a Straight Cut . . . . . 86
139	Examples of Good and Poor Cut Quality. . . . . 87
140	Straight Cut Angle(s) . . . . . 87
141	Cutting Tip Height . . . . . 87
142	Cutting Tip Speed. . . . . 88
143	Close the Oxygen Cylinder Valve . . . . . 89
144	Open the Oxygen Torch Valve on the Cutting Attachment to Initially Drain the Oxygen System – First. . . . . 89
145	Open the Oxygen Torch Valve on the Torch Handle to Completely Drain the Oxygen System – Second . . . . . 90
146	Turn the Adjusting Screw Counterclockwise on the Oxygen Regulator . . . . . 90
147	Close the Oxygen Torch Valve on the Torch Handle – First . . . . . 90
148	Close the Oxygen Torch Valve on the Cutting Attachment – Second . . . . . 91
149	Close the Acetylene Cylinder Valve. . . . . 91
150	Open the Acetylene Torch Valve on the Torch Handle Draining the Acetylene System . . . . . 92
151	Backing Out the Adjusting Screw on the Acetylene Regulator . . . . . 92
152	Closing the Acetylene Torch Valve on the Torch Handle. . . . . 93
D.1	Oxyacetylene Cutting System on a 2-Wheeled Cart . . . . . 105
D.2	Welding Tip and Torch Mixer Attached to Torch Handle . . . . . 106
D.3	Welding Tip and Torch Mixer Detached from Torch Handle. . . . . 106
D.4	Connecting a Cutting Attachment to the Torch Handle . . . . . 106
D.5	Cutting Attachment Connected to Torch Handle . . . . . 107
D.6	Combination (Hand) Cutting Torch . . . . . 107
D.7	Commercial (Straight) Cutting Torch . . . . . 108
D.8	Cutting Tip . . . . . 108
D.9	There should be No Pressure (Open or Loose) on Adjusting Screws of either the Oxygen or Acetylene Regulators. . . . . 110
D.10	Opening the Acetylene Cylinder Valve with Pressure on Cylinder Side but Not Output Side . . . . . 110
D.11	Opening the Oxygen Cylinder Valve with Pressure on Cylinder Side but Not Output Side . . . . . 111
D.12	Adjust Acetylene Regulator for Desired Static Pressure on the Output Side with Pressure on the Cylinder Side. . . . . 111
D.13	Open the Acetylene Torch Valve on the Torch Handle . . . . . 112
D.14	Readjust the Acetylene Regulator Adjusting Screw for the Correct Dynamic Pressure . . . . . 112
D.15	Close the Acetylene Torch Valve on the Torch Handle . . . . . 113
D.16	Adjust Oxygen Regulator for Desired Static Pressure on the Output Side and Pressure on the Cylinder Side. . . . . 113
D.17	Fully Open the Oxygen Valve on the Torch Handle – First . . . . . 114
D.18	Open the Oxygen Needle Valve on the Cutting Attachment – Second . . . . . 114
D.19	Readjust the Oxygen Regulator Adjusting Screw for the Correct Dynamic Pressure . . . . . 115
D.20	Close the Oxygen Torch Valve on the Cutting Attachment – Only . . . . . 115

<b>Figure</b>	<b>Page No.</b>
D.21	Open the Acetylene Torch Valve on the Torch Handle . . . . . 116
D.22	Light the Torch with a Friction Lighter . . . . . 116
D.23	Acetylene Flame after Lighting with a Friction Lighter . . . . . 117
D.24	Adjusting the Size of the Acetylene Flame with the Acetylene Torch Valve on the Torch Handle . . . . . 117
D.25	Acetylene Flame Burning in Air with Only Acetylene from the Acetylene Torch Valve on the Torch Handle . . . . . 118
D.26	Adjusting the Carburizing or Reducing Flame with Some (Too Little) Oxygen Using the Oxygen Torch Valve on the Cutting Attachment . . . . . 118
D.27	Adjusting the Neutral Flame with More Oxygen Using the Oxygen Torch Valve on the Cutting Attachment . . . . . 119
D.28	Adjusting the Neutral Flame with Cutting Oxygen Stream Using the Oxygen Cutting Lever on the Cutting Attachment . . . . . 119
D.29	Adjusting the Oxidizing Flame with Excessive Oxygen Using the Oxygen Valve on the Cutting Attachment . . . . . 120
D.30	Basic Flames of Oxyacetylene Cutting . . . . . 120
D.31	A Bevel Cut . . . . . 121
D.32	Torch Angle(s) for a Bevel Cut . . . . . 121
D.33	Torch Height for a Bevel Cut . . . . . 122
D.34	Torch Speed for a Bevel Cut . . . . . 122
D.35	Start a Bevel Cut . . . . . 123
D.36	Run a Bevel Cut . . . . . 123
D.37	Stop a Bevel Cut . . . . . 124
D.38	Bevel Cut Quality . . . . . 124
D.39	Piercing a Hole . . . . . 125
D.40	Torch Angles(s) for Piercing a Hole . . . . . 125
D.41	Torch Height for Piercing a Hole . . . . . 126
D.42	Torch Speed for Piercing a Hole . . . . . 126
D.43	Start Piercing a Hole . . . . . 127
D.44	Continuing to Pierce a Hole . . . . . 127
D.45	Stop Piercing a Hole . . . . . 128
D.46	Pierce Hole Cut Quality . . . . . 128
D.47	Marking Out the Shape of Your State . . . . . 129
D.48	Cutting the Shape of Your State . . . . . 129
D.49	Torch Angle(s) for the Shape of Your State . . . . . 130
D.50	Torch Height for the Shape of Your State . . . . . 130
D.51	Torch Speed for the Shape of Your State . . . . . 131
D.52	Start a Cut of the Shape of Your State . . . . . 131
D.53	Run the Cut of the Shape of Your State . . . . . 132
D.54	Stop the Cut of the Shape of Your State . . . . . 132
D.55	Shape of Your State Cut Quality . . . . . 133
D.56	Cut Quality . . . . . 134
D.57	Cutting Tip Angle(s) . . . . . 134
D.58	Cutting Tip Height . . . . . 135
D.59	Cutting Tip Speed . . . . . 135
D.60	Pre-Heat Temperature . . . . . 136
D.61	Cutting Oxygen . . . . . 136
D.62	Extreme Cutting Tip Speed . . . . . 137
D.63	Inconsistent Travel Speed . . . . . 137
D.64	Restricted Tip . . . . . 138
D.65	Inconsistent Pressure . . . . . 138
D.66	Lost Cut . . . . . 138
D.67	Close the Oxygen Cylinder Valve . . . . . 139
D.68	Open the Oxygen Torch Valve on the Cutting Attachment to Initially Drain the Oxygen System – First . . . . . 140



<b>Figure</b>	<b>Page No.</b>
D.69	Open the Oxygen Torch Valve on the Torch Handle to Completely Drain the Oxygen System – Second. . . . . 140
D.70	Turn the Adjusting Screw Counterclockwise on the Oxygen Regulator . . . . . 141
D.71	Close the Oxygen Torch Valve on the Torch Handle – First . . . . . 141
D.72	Close the Oxygen Torch Valve on the Cutting Attachment – Second . . . . . 141
D.73	Close the Acetylene Cylinder Valve. . . . . 142
D.74	Open the Acetylene Torch Valve on the Torch Handle Draining the Acetylene System. . . . . 142
D.75	Backing Out the Adjusting Screw on the Acetylene Regulator . . . . . 143
D.76	Closing the Acetylene Torch Valve on the Torch Handle. . . . . 143

# Recommended Practices for Oxyacetylene Cutting of Steel

## 1. General Requirements

**1.1 Scope.** This recommended practice describes the equipment, procedures, and safe practices for the oxyacetylene cutting of steel. This oxy-fuel gas cutting (OFC-A) process is the most used process for cutting carbon steel; however, it is sometimes used on alloy steel and cast iron. The fuel gas generally used is acetylene, and it will be the fuel gas used throughout this recommended practice. Although oxyacetylene cutting (OFC-A) can be used for semi-automatic and automatic cutting, only manual cutting will be discussed in this recommended practice. Manual cutting using hand torches are recommended for users (cutters otherwise students) and management (managers otherwise supervisors) or administration (instructors otherwise teachers) associated with the OFC-A process. The users can choose to implement the entire AWS C4.9/C4.9M as a comprehensive recommended practice or selectively use specific sections (clauses and annexes) based on their needs and settings. In short, these guidelines for oxyacetylene cutting of steel offer flexibility in how this recommended practice can be applied in various educational and practical settings to cater to a wide range of users

Oxyacetylene cutting (OFC-A) is a process where a metal (usually an iron base alloy) is heated to its ignition temperature (well below its kindling temperature) by an oxyacetylene flame. A cutting torch is used for this operation as a regulated jet of oxygen from the cutting torch causes the metal to be oxidized quickly into liquid iron oxide that flows out of the kerf as dross, producing the cut. Acetylene is the fuel gas of choice because it has the ability, along with oxygen, to form a gaseous shield around the cherry red metal (around 1400°F [760°C]), protecting it from ambient contaminants as the cut progresses. Virtually all commercial fuel gases can produce temperatures high enough to liquefy most metals and allow cuts to occur in the realm of pure oxygen. However, acetylene remains the fuel gas of choice as OFC-A (whether implementing reducing, neutral, or oxidizing flames) is easier to adjust compared to other fuel gas mixtures. OFC-A is used in fabrication, maintenance, and repair, where flexibility and mobility are important.

Although this recommended practice is not written with mandatory requirements, mandatory language, such as the use of “shall,” will be found in those portions of the document where failure to follow the instructions or procedures could produce inferior, misleading, or unsafe results.

Appropriate terms and definitions from AWS A3.0M/A3.0, *Standard Welding Terms and Definitions, Including Terms for Adhesive Bonding, Brazing, Soldering, Thermal Cutting, and Thermal Spraying*, are included in Annex B of this Recommended Practice for information only.

**1.2 Units of Measure.** This standard (recommended practice) uses both U.S. Customary Units and the International System of Units (SI). The latter are shown within brackets ([ ]) or in appropriate columns in tables and figures. The measurements may not be exact equivalents; therefore, each system must be used independently.

**1.3 Safety.** Safety issues and concerns are addressed in this standard (recommended practice), although some health issues are beyond the scope of this standard (recommended practice).

Safety and health information is available from the following sources:

American Welding Society:

- (1) ANSI Z49.1, *Safety in Welding, Cutting, and Allied Processes*
- (2) ANSI Z87.1, *American National Standard for Occupational and Educational Eye and Face Protection*
- (3) ANSI Z89.1, *Industrial Head Protection*
- (4) AWS Safety and Health Fact Sheets
- (5) Other safety and health information on the AWS website